



# Sony Ericsson s710a SIM Card Replacement

This guide will walk you through how to install/replace the SIM card in the Sony Ericsson s710a cellular phone.

Written By: Alexander



## INTRODUCTION

This is a GSM phone originally introduced by AT&T. The SIM card will likely be an AT&T card; however, when in foreign countries, other SIM cards can be inserted into the phone for compatibility with foreign carriers.

## Step 1 — SIM Card



- Slide the battery cover off by pushing it away from the camera side of the device.

ⓘ This may require a good amount of force.

## Step 2



- Next remove the battery
- Lift it out of the phone using the tab on the battery (marked in the image)

### Step 3



- The SIM card holder is now exposed (marked in image).
- This will likely already have an existing SIM card in it if the phone has been previously used.
- To open this, slide the holder upward (assuming the same orientation as in the image)

### Step 4



- The holder will then hinge open.
- You are now able to insert a new SIM card.



## Step 5



- Insert the new SIM card in the orientation shown.
- ⓘ This is important, as the phone will not work if the metal contacts on the card are not properly aligned with the contacts on the phone.

## Step 6



- Now hinge the SIM card holder down so that it lays flat in the phone.
- Slide the plastic holder downwards to lock it in place.
- Now the battery and cover can be put back in place.

To reassemble your device, follow these instructions in reverse order.